

## RAM ball/mount installation – Triton MR

- Remove driver side grab handle bolt covers
- Cut plastic cover trim supports from the BOTTOM plastic cover:



- Remove bolts from grip handle and remove handle from vehicle
- Insert black spacer to bottom bolt location



- Fit plastic cover back over spacer
- Drill through plastic cover from the back of the handle, using the installed spacer as a drill guide. Use a 6mm drill bit.



- Re-install grip handle. For the bottom, use supplied bolt and RAM ball as per photo below (black spacer needs to stay inside the bottom bolt cavity under the cover):



- Do not over-tighten the bolt (around 4Nm).